

Printer Configuration

The printer driver works with following printer configuration !
Benötigte Druckereinstellungen !

CURRENT USER: MACRO

MACRO

CONFIGURE

INTERFACE: CX
RS1 EMULATION:
BAUD RATE (RS1):
BITS/CHARACTER (RS1):
PARITY (RS1):
STOP BITS (RS1):
DSR (RS1):
C X EMULATION: LQ
C X STROBE EDGE: RISING EDGE
CHINESE CODE STD: GB18030
DRAFT SPEED: HIGH SPEED
LQ TYPE: LQ2
NEEDLES SWITCH: YES
SPECIAL FORMS: NO
BIM DIRECTION: BIDIRECTION
NEEDLE COMPENSATION: NO
PNS #2000K: SINGLE SHEET
PNS #2001K: 400
PNS #2002K: NO
PNS #2003K: NO
PNS #2004K: 205mm
PNS #2005K: NO
PNS #2006K: NO

LQ CONFIGURE

AUTO COMPRESSION: NO
LINE LENGTH COMPRESS: NO
COMPRESS PROPORTION: 108/LINE (80%)
FAN FOLD LEFT MARG.: 0
PAPER EMPTY WARNING: YES
PRINTING MODE: LATIN
HIGH SPEED PRINTING: NO
LPI: 6
C PI OF CJK FONT: 6.7
C PI OF WEST FONT: 10
XPI LOCKED: NO
CHARACTER, SET: PC
PC CHARACTER SET: 1250 (PC-WIN LATIN2)
CHARACTER DEFINITION: LQ
LF+CR: YES
CR+LF: NO
LEFT MARG. (1/6"): 0
LEFT MARG. (1/60"): 0
TOP MARG. (1/6"): 0
TOP MARG. (1/60"): 0
ZERO SLASH: NO
LINE LENGTH: 94
RESET WHEN EJECT: NO