The Spooltool is a simple Tool to download firmware or send print files to a installed Windows printer. Copies and delay between the printfiles can be selected. A file list can be drawn up. Files can be added or deleted.

PSi WinSpool Tool 2.0 beta

Write to Spool of Printer:
PSi PP405WL

Source File:
J:\Dokumente und Einstellungen\Panthel.NT\Desktop\I_04080

J:\Dokumente und Einstellungen\Panthel.NT\Desktop\I_040806.MOT

Auto Repeat
☐ enabled

Copies: 1   0-infinit.
Delay: 30   sec

Results
Loops made:
Files processed:
Elapsed time:
Next event:

Copyright (c) 1998 by PSi GmbH written by Michael Hessmann, modified by Rolf Boesehans 2002

Help   Start   Quit

Select an installed Windows Printer

Select one or more print files

To unselect print files mark it by a left mouse click and delete it then by right mouse click

Start printing

selection for Copies and delay between the print files if necessary